

**Description****ACTIVATOR PER ANAEROBICS****ACTIVATOR**

Activates passive metal surfaces (zincate, cadmate or stainless steel) and encourages the reaction between anaerobic and metal on threaded or cylindrical couplings.

**ACCELERANT**

Enables cylindrical or threaded couplings to be assembled in a few minutes. (1-2 min. maximum)

**DEGREASER**

Cleanses the surfaces by removing any oily films.

**Details****Chemical-physical properties**

Properties	Description
Base	Acetone
Colour	Light green
Viscosity at 22°C	2 mPa.s
Density at 25°C	0.790 kg/l
Ignition Point	-8°C

**PRECAUTIONS:** Take care to use the product in an adequately ventilated room. Do not use the product near flames.

Protect any electrical systems from product spray.

**Advice for use**

- Spray P730 on one or both the perfectly clean surfaces to be assembled.
- Wait for the solvent to evaporate and the surfaces are dry. Carry out the operation in a well-ventilated room.
- After activation, the pieces should be assembled within two hours.

**STORAGE:**

The activator is flammable. We advise you to keep it far from heat sources, oxidizing agents and other combustible products. Close the cap on the aerosol after use.

**Packaging available**

200ml Spray

The information in this technical sheet is based on the specifications and potential use known to us. However, this data does not imply any legal obligation or liability whatsoever.

REGISTERED OFFICE  
Via Domenico Scarlatti, 26  
20124 Milan



Commercial Offices and Plant  
Corso Europa, 91 – 20020 Solaro (MI)  
[info@farmicol.com](mailto:info@farmicol.com)  
Customer Service +39 02 84505409  
[www.faren.com](http://www.faren.com)